

Jacuzzi


Voda v Jacuzziju je 37,5 stopnj NE SPREMINJAJ toplote vode

Water in Jacuzzi is 37,5 degrees DO NOT change it

Za masažo uporabljaj samo gum 1 in 2, for massage use only button 1 and 2.



Nivo vode mora biti najmanj do vzglavnika, Water leve must be minimally under the pillow as it's shown.



V kolikor nivo vode pade pod vzglavnik ga napolnite, vzemite cev in dotočite. V nasprotnem primeru se bo vodna črpalka skurila in uničila. Popravilo vam bomo zaračunali.

In case if water level will drop under pillow you must refill it. Take water from the pipe, it will take 2 minutes. In other case the pump will be destroyed. We will charge you for the repair.

